



“GET STIPPLED”

Shop Address:
84/86 Industry Drive
Tweed Heads South,
NSW 2486

Postal Address:
P.O. Box 351,
Banora Point,
N.S.W. 2486

Phone:
+61 7 55244 235 or
+61 7 55233 539

Fax:
+61 7 5524 6940

Web: www.getstippled.com
E-Mail: info@getstippled.com



INTERIOR/ EXTERIOR WALL AND CEILING TEXTURE COATINGS

ULTRATEX ULTRAFINE

THIS MATERIAL TESTED BY THE CSIRO AND COMPLIES WITH ASINZS 1530.3:1999.

WE GUARANTEE OUR PRODUCTS WHEN USED IN ACCORDANCE WITH OUR COMPLETE SYSTEM AND APPLIED USING THE BEST ACCEPTED TRADE PRACTICES.

DESCRIPTION:

A 100% acrylic, heavy-duty membrane low-build profile roll-on texture coating, used when longevity of coating is required but cost is a prime consideration. This product can be used on most masonry surfaces in a two-coat application without the need for a primer/sealer, but a sealer is always recommended.

USE ON:

Cement render, tilt-up concrete, AAC blocks and panels, off-form concrete, Harditex sheeting, blueboard, concrete blocks and clay bricks etc (refer to notes on skim-coats patching). Suitable for housing, commercial, high rise, blockwork/blueboard fences and any suitably prepared masonry surfaces.

COLOUR RANGE:

White, accent and ultra deep bases allows unlimited choice of colours.

PROPERTIES:

Profile:	Sandy Fine/Medium
Surface:	Fine/Medium
Dry film:	Up to 0.5mm at peak
Weather Resistance	Excellent
Solvent:	Water
Odour:	Low (Wet) nil (Dry)

SURFACE PREPARATION:

Refer notes on SUBSTRATES.

APPLICATION METHOD # 1. (RECOMMENDED)

1. Apply one coat of ULTRATEX TEXPRIME with a lambswool roller, brush or spray. Allow 4 hours to dry.
2. Apply one coat of ULTRATEX ULTRAFINE with a lambswool roller, brush or spray. Allow 4 hours to dry.
3. Apply one coat of ULTRATEX ULTRAFINE with a lambswool roller, brush or spray. Allow 4 hours to dry.

APPLICATION METHOD # 2. (TWO COAT)

1. Apply one coat of ULTRATEX ULTRAFINE with a lambswool roller, brush or spray. Allow up to 4 hours to dry.
2. Repeat step # 1

NOTE;

These application methods will give you a profile which will look like sponge-finish cement render

FOR EXTRA PROTECTION USE ONE EXTRA COAT OF ULTRATEX PROTECT SATIN or ULTRATEX SUPAFLEX

PACKAGING:

ULTRATEX ULTRAFINE is supplied in ready for use re-sealable 4ltr and 15ltr plastic containers.